Download the latest firmware from the internet and updating the device using a memory card with your PC

 Make sure your SD card is formatted and copy the KWDBAZFW.BIN into the root directory of the SD card.

Notice: Make sure the file name is KWDBAZFW.BIN If you see KWDBAZFW.BIN(1) or so on, please rename the file name to KWDBAZFW.BIN


a Carl Star Star		Rangelanted			0 ×		 LUTRADASH	_	
+ Withdown			~8		n (*		●	9	
	:	PHOTO PHOTOCIUM HERO	20000-0444 20070-0444 20070-0444	Fachilier Fachilier Fachilier	Sa.	AlDrag Viceo	 PROTECTED		KAROLUTIN (#1

2. Insert the SD card into the dashcam.



Connect Dash Cam to your PC or Mac with the 3rd party USB A to USB C cable, and make sure the dashcam is charging.

The device does not support Type-C USB cables with PD (Power Delivery) fast charging or USB-C to USB-C cables.



 When turning on the dashcam, select Dash Cam and there will be a popup message as picture below. Please press OK button to start the update.



 When the update starts, there will be a popup message as picture below. DO NOT TURN OFF OR PRESS ANY BUTTON DURING THIS PERIOD, IT MAY CAUSE THE UPDATE FAILURE.



It may take a while for updating. Once it finishes the update, DRV-A610W will turn off the device automatically.



7. Turn on the dash cam and reset the first time settings. Press MENU button twice to enter SETUP MENU and select the System Info and select Firmware Version. Long press the Record Button to display the Rear Camera Firmware. Check if the version matches the latest one [V1.0_ABCDEF_A] as shown on website, then it is successfully updated.

